




NO	Description
1	Tapping Screw
2	Left Enclosure
3	Adjusting Screw
4	Connecting Plate
5	Base Plate
6	Metal Pendulum Switch
7	Roller Spring
8	Saw Holder Pin
9	Rolling Metal Guide
10	Roller Pin
11	Support Roller
12	Circlip
13	Holder For Saw Arm
14	Spring
15	Socket Head Screw
16	Saw Holder
17	Saw Arm
18	Holder For Saw Arm
19	Roller
20	Fixing Ring
21	Washer
22	Needle Roller Bearing
23	Big Gearing
24	Balance Block
25	Lifting Knife Plate
26	Bearing Holder
27	Bearing
28	Rotor
29	Brush Holder
30	Carbon Brush
31	Brush Bushing
32	Bearing
33	Stator
34	Cord Sleeve
35	AC Cord & Plug

NO	Description
36	Dust Connection
37	"O" type Ring
38	Strain Relief
39	Tapping Screw
40	Rubber Pin
41	Square Nut
42	Protecting Wire
43	Laser Head
44	Laser Facility
45	Screw
46	Laser Head Button
47	Square Nut
48	Pendulum Switch Knob
49	Right Enclosure
50	PCB
51	Transformer
52	Switch
53	PCB
54	Capacitance
55	
56	
57	
58	
59	
60	
61	
62	
63	
64	
65	
66	
67	
68	
69	
70	