



| No. | ΚΩΔ. | ΠΕΡΙΓΡΑΦΗ | ΠΟΣ. |
|-----|-------|--|------|
| 1 | 66654 | Dust cap | 1 |
| 2 | 66655 | Roundwire snap rings for shaft 18×1.8 | 1 |
| 3 | 66656 | Steel ball holder | 1 |
| 4 | 69812 | Spring | 1 |
| 5 | - | Circlip for shaft 30 | 4 |
| 6 | - | Screw | 1 |
| 7 | - | Cylinder case | 1 |
| 8 | - | Ring | 1 |
| 9 | - | Bearing 61906 | 1 |
| 10 | - | Spring | 1 |
| 11 | 75498 | Sliding sleeve | 1 |
| 12 | - | Circlip for hole 22 | 1 |
| 13 | - | Spring | 1 |
| 14 | 69813 | Clutch | 1 |
| 15 | 69814 | Roundwire snap rings for shaft 27×1.8 | 1 |
| 16 | 69815 | Bevel gear | 1 |
| 17 | - | O ring 28 | 1 |
| 18 | - | Drill sleeve | 4 |
| 19 | - | Steel ball 7.14 | 1 |
| 20 | 69811 | Ball frame spring | 1 |
| 21 | 72730 | X ring23 | 1 |
| 22 | 72732 | X ring13 | 1 |
| 23 | 72733 | Impact bar | 2 |
| 24 | - | Flat key 3×3×16 | 1 |
| 25 | 66657 | Cylinder | 1 |
| 26 | - | Spring | 1 |
| 27 | - | Striker | 1 |
| 28 | 66658 | O ring 19 | 1 |
| 29 | 69817 | Piston pin | 1 |
| 30 | 66659 | Piston | 1 |
| 31 | 66660 | Steel sleeve 8*12*10 | 1 |
| 32 | 66661 | Connecting rod | 1 |
| 33 | - | Circlip for hole 47 | 1 |
| 34 | - | Oil bearing | 1 |
| 35 | - | Carbon brush alarm wire | 1 |

| No. | ΚΩΔ. | ΠΕΡΙΓΡΑΦΗ | ΠΟΣ. |
|-----|-------|---|------|
| 36 | 66662 | Bevel pinion | 1 |
| 37 | 69816 | Distance ring | 1 |
| 38 | 71982 | Bearing 6002 | 2 |
| 39 | - | Adjusting washer | 1 |
| 40 | 66663 | Second gear | 1 |
| 41 | - | Tripping plate | 1 |
| 42 | - | Circlip for shaft 12.5 | 1 |
| 43 | - | Steel ball 5 | 8 |
| 44 | - | Cylindrical pin | 1 |
| 45 | 71983 | Disc spring | 2 |
| 46 | 71981 | Oil filler cap | 1 |
| 47 | - | Self-locking nut M10 | 1 |
| 48 | - | Bearing 627 | 1 |
| 49 | 66664 | Crank shaft | 1 |
| 50 | - | O ring | 1 |
| 51 | - | Circlip for hole32 | 1 |
| 52 | 75674 | Circlip for shaft 15 | 1 |
| 53 | - | Clutch spring | 1 |
| 54 | 74620 | Hammer clutch | 1 |
| 55 | 66665 | First gear | 1 |
| 56 | - | Roundwire snap rings for shaft 8.5×1.2 | 1 |
| 57 | - | Steel sleeve 8×12×10 | 1 |
| 58 | 75103 | Gearbox | 1 |
| 59 | - | Absorber boot | 1 |
| 60 | - | Spring | 1 |
| 61 | - | Support ring | 1 |
| 62 | - | Vibration bolt | 2 |
| 63 | - | Gearbox cover | 1 |
| 64 | - | Bearing 6001 | 1 |
| 65 | - | Windshield | 1 |
| 66 | 66666 | Rotor | 1 |
| 67 | - | Bearing 608 | 1 |
| 68 | - | Screw | 2 |
| 69 | 66667 | Stator | 1 |
| 70 | 75102 | Housing | 1 |
| 71 | - | Tail cover | 1 |

| No. | ΚΩΔ. | ΠΕΡΙΓΡΑΦΗ | ΠΟΣ. |
|-------|-------|-------------------------------------|------|
| 72 | - | Screw | 9 |
| 73 | - | Coil spring | 2 |
| 74 | 66668 | Brush | 2 |
| 75 | - | Brush carrier | 2 |
| 76 | - | Screw | 3 |
| 77 | - | Screw | 4 |
| 78 | - | Carbon brush alarm contact sheet | 1 |
| 79 | 66669 | Function shifter lever | 1 |
| 80 | - | Circlip for shaft 15 | 1 |
| 81 | 66670 | Shifting fork | 1 |
| 82 | 66671 | Fork setting plate | 1 |
| 83 | - | Screw | 1 |
| 84 | 66672 | Mode selector switch | 1 |
| 85 | 66673 | Self-lock button | 1 |
| 86 | - | O ring | 1 |
| 87 | - | Left side cover | 1 |
| 88 | - | Right side cover | 1 |
| 89 | - | Left handle | 1 |
| 90 | - | Right handle | 1 |
| 91 | 66674 | Switch | 1 |
| 92 | - | Locknut | 1 |
| 93 | - | Inside hexagonal bolt | 1 |
| 94 | 66675 | Speed-control switch | 1 |
| 95 | - | Screw | 2 |
| 96 | - | Cable pressing plate | 1 |
| 97 | - | Cable sheath | 1 |
| 98 | - | Cord | 1 |
| 99 | 66676 | Hoop | 1 |
| 100 | - | Bracket | 1 |
| 101 | - | T screw | 1 |
| 102 | - | Auxiliary handle | 1 |
| 103 | - | Locking button | 1 |
| 104 | - | Spring | 1 |
| 200 | 66677 | Handle assembly | 1 |
| 33-48 | 71852 | Motion cog | 1 |