


BRUSHLESS



No.	ΠΕΡΙΓΡΑΦΗ	ΠΟΣ.
1	ST3.5×16 Self-tapping Screw	11
2	IW4038S Lamp Cover	1
3	IW4038SH Gearbox Assembly	1
3.1	IW4038S Gearbox Front Housing Assembly	1
3.1.1	Steel Sleeve	1
3.2	Output Shaft Gasket	1
3.3	O-Ring	1
3.4	IW4038SH Impact Shaft	1
3.5	Impact Block	1
3.6	Planetary Gear	3
3.7	IW4038 Pin	3
3.8	Planetary Gear Pin Gasket	1
3.9	Internal Ring Gear	1
3.1	Deep Groove Ball Bearing	1
3.11	IW2040 O-Ring	1
3.12	Impact Block End Cover	1
4	Stator Control Board Assembly	1
4.1	Brushless Motor Stator	1
4.2	IW30 Switch	1
4.3	IW2038S Control Board	1
4.4	Body Bracket (B3)	1
5	O-Ring	1
6	Brushless Motor Rotor Assembly	1
6.1	Motor Shaft Gear	1
6.2	GWIW02 Rotor Gasket	1
6.3	Brushless Motor Rotor	1
7	IW4038S Housing End Cap	1
8	CD1028 Reversing Lever (CD08)	1
9	Left and Right Housing	1
10	ST3.5×12 Self-tapping Screw	4
11	Button Panel	1