



No.	ΠΕΡΙΓΡΑΦΗ	ΠΟΣ.
1	Dust Cap	1
2	Ring spring 25	1
3	Washer 28×48×3	1
4	Spring 28.5×20×1.5	1
5	Washer 28.1×33×1.5	1
6	Steel ball holder	1
7	Spring 35×5752	1
8	Spring support	1
9	Socket head cap screw M5×25-8.8	4
10	Spring washer 5	4
11	Flat washer 5	4
12	Cylinder case	1
13	Oil seal 51×35×6	1
14	Washer 45×55×1	1
15	Ring spring 32.5×2	1
16	Bearing 6907RS-FD	1
17	Distance ring 55×40×4	1
18	Washer 45×55×1	1
19	Rubber ring 55×47×7	1
20	Washer 45×55×1	1
21	Circlip for hole 55	1
22	Stop spring 55×35×2	1
23	Stop ring	1
24	Roundwire snap rings for hole 59×1.6	1
25	Steel column 8×19.25	2
26	Drill sleeve	1
27	O ring 23.8×2.1	2
28	O ring 15×2	2
29	Impact bar	1
30	Steel ball 10.5	3
31	Flat key 3×3×18	2
32	Cylinder	1
33	Spring 37×68×2.5	1
34	Clutch	1
35	Roundwire snap rings for shaft 33.5×1.5	1
36	Bevel gear wheel	1
37	Striker	1
38	O ring 21.8×3.1	1
39	Piston pin 8×26.8	2
40	Piston	1
41	Needle roller bearing HK10×16×12	1
42	Connecting rod	1
43	Circlip for hole 50	1
44	Oil bearing 34×50×10	1
45	Inside cover	1
46	Outside cover	1
47	"+" pan head screw M4×14	4
48	Spring washer 4	4
49	Flat washer 4	4
50	O ring (43x)39×2	1
51	Crank shaft	1
52	Gearbox	1
53	Spring Φ1.8xΦ16×42	1
54	Washer	1
55	Bolt M10×61	1
56	Bearing 6003RZ-C&U	1
57	Circlip for hole 35	1
58	Flat key 4×12	1
59	First gear	1
60	Circlip for shaft 15	1
61	Needle roller bearing HK1210	1
62	Bevel pinion	1
63	Flat key 3×10	1
64	Bearing 6002RZ-C&U	1
65	Washer Φ20×Φ14×0.5	1
66	Gear pressing plate	1
67	Second gear	1
68	Steel ball 5.5	8
69	Spring Φ1.1×Φ5.8×13.2	8
70	Gear holder	1
71	Nut	1
72	Bearing 627RZ-C&U	1
73	Gasket ring	1
74	Gearbox cover	1
75	Flat washer 5	3
76	Spring washer 5	3
77	Socket head cap screw M5×25-8.8	3
78	Bearing 6001RZ-C&U	1
79	Rotor	1
80	Bearing 608RZ-C&U	1
81	Wind deflector	1
82	"+"pan head tapping screw ST5×65	2
83	Lock washer 5	1
84	Stator	1
85	Motor casing	1
86	Socket head cap screw and washer assembly M5×45	2
87	Socket head cap screw and washer assembly M5×65	2
88	Brush carrier	2
89	Brush box	2
90	Rubber column 5×6	2
91	Brush	2
92	Tail cover	1
93	"+"pan head tapping screw ST4.2×16	2
94	Release button	1
95	Spring Φ0.6×Φ5.5×25	1
96	Mode selector switch (drill stop)	1
97	O ring 11×2	1
98	Rotating shaft	1
99	Circlip for hole 18	1
100	Flat washer 5	1
101	Spring washer 5	1
102	"+" pan head screw M5×16	1
103	"+" pan head screw M4×14	1
104	Spring washer 4	1
105	Flat washer 4	1
106	Left side cover	1
107	Right side cover	1
108	"+" pan head tapping screw ST4.2×16	2
109	Flat washer 4	1
110	Spring washer 4	1
111	"+" pan head screw M4×14	1
112	Right rear cover	1
113	"+" pan head tapping screw ST4×16	4
114	"+" pan head screw M4×14	2
115	Spring washer 4	2
116	Flat washer 4	2
117	Absorber boot	1
118	Left rear cover	1
119	Speed controller	1
120	Flat washer 4	1
121	Spring washer 4	1
122	"+"pan head screw M4×14	1
123	Socket head cap screw M6×50	1
124	Flat washer 6	1
125	Left handle	1
127	Capacitance 0.33	1
128	Switch	1
129	"+"pan head tapping screw ST4×16	8
130	Right handle	1
131	Self-locking nut M6	1
132	"+"pan head tapping screw ST4×16	2
133	Indicator light pressing plate	1
134	Indicator light cap	1
135	Indicator light	1
136	Indicator light cover	1
137	"+"pan head tapping screw ST4.2×16	2
138	Cable pressing plate	1
139	Cable sheath	1
140	Supply cord H07RN-F2×1.0-2.3	1
141	Square head screw M8×55	1
142	Hoop pressing plate	1
143	Hoop	1
144	Clamp screw	1
145	Bracket	1
146	Hex.nut M6	1
147	Self-locking nut M6	1
148	Assistant handle	1
149	Depth gauge 6×300	1
150	O ring 67	1

No.	ΠΕΡΙΓΡΑΦΗ	ΠΟΣ.
78	Bearing 6001RZ-C&U	1
79	Rotor	1
80	Bearing 608RZ-C&U	1
81	Wind deflector	1
82	"+"pan head tapping screw ST5×65	2
83	Lock washer 5	1
84	Stator	1
85	Motor casing	1
86	Socket head cap screw and washer assembly M5×45	2
87	Socket head cap screw and washer assembly M5×65	2
88	Brush carrier	2
89	Brush box	2
90	Rubber column 5×6	2
91	Brush	2
92	Tail cover	1
93	"+"pan head tapping screw ST4.2×16	2
94	Release button	1
95	Spring Φ0.6×Φ5.5×25	1
96	Mode selector switch (drill stop)	1
97	O ring 11×2	1
98	Rotating shaft	1
99	Circlip for hole 18	1
100	Flat washer 5	1
101	Spring washer 5	1
102	"+" pan head screw M5×16	1
103	"+" pan head screw M4×14	1
104	Spring washer 4	1
105	Flat washer 4	1
106	Left side cover	1
107	Right side cover	1
108	"+" pan head tapping screw ST4.2×16	2
109	Flat washer 4	1
110	Spring washer 4	1
111	"+" pan head screw M4×14	1
112	Right rear cover	1
113	"+" pan head tapping screw ST4×16	4
114	"+" pan head screw M4×14	2
115	Spring washer 4	2
116	Flat washer 4	2
117	Absorber boot	1
118	Left rear cover	1
119	Speed controller	1
120	Flat washer 4	1
121	Spring washer 4	1
122	"+"pan head screw M4×14	1
123	Socket head cap screw M6×50	1
124	Flat washer 6	1
125	Left handle	1
127	Capacitance 0.33	1
128	Switch	1
129	"+"pan head tapping screw ST4×16	8
130	Right handle	1
131	Self-locking nut M6	1
132	"+"pan head tapping screw ST4×16	2
133	Indicator light pressing plate	1
134	Indicator light cap	1
135	Indicator light	1
136	Indicator light cover	1
137	"+"pan head tapping screw ST4.2×16	2
138	Cable pressing plate	1
139	Cable sheath	1
140	Supply cord H07RN-F2×1.0-2.3	1
141	Square head screw M8×55	1
142	Hoop pressing plate	1
143	Hoop	1
144	Clamp screw	1
145	Bracket	1
146	Hex.nut M6	1
147	Self-locking nut M6	1
148	Assistant handle	1
149	Depth gauge 6×300	1
150	O ring 67	1