



No.	ΠΕΡΙΓΡΑΦΗ	ΠΟΣ.
1	Fan cover	2
2	Left fan	1
3	Left crankcase	1
4	Connecting rod	2
5	Piston ring	2
6	Fasten plate	2
7	Fasten plate screw	2
8	Cylinder	2
9	Cylinder sealing ring	2
10	Outlet valve	4
11	Fasten part	2
12	Fasten part screw	1
13	Cylinder head sealing ring	2
14	Cylinder head	2
15	Head cover screw	8
16	Air filter	1
17	Plastic handle	1
18	Fasten screw	2
19	Plastic handle cover	1
20	Valve plate	2
21	Intake valve	2
22	Metal gasket	2
23	Right fan	1
24	Crank	2
25	Crank screw	2
26	Crank bearing	2
27	Connecting rod screw	2
28	Right crankcase	1
29	Screw	4
30	Light spring washer	4
31	Stator	1
32	Nut	4
33	Rotor	1
34	Motor bearing	2
35	Anti-vibration feet	4
36	Spring washer	4
37	Nut	4
38	Elbow bend	2
39	Metal hose	2
40	Check valve	1
42	Screw	2
43	Capacitor box	1
44	Capacitor	1
45	Pressure gauge	1
46	Pressure switch	1
47	Quick coupling	1
48	Safety valve	1
49	Unloading tube	1
50	Power cable	1
51	Air tank	1
52	Rubber feet	4
53	Nut	4
54	Spring washer	1
55	Screw	1
56	Drain valve	1