



No.	ΠΕΡΙΓΡΑΦΗ	ΠΟΣ.
1	Fan cover	2
2	Left fan	1
3	Left crankcase	1
4	Connecting rod	2
5	Piston ring	2
6	Fasten plate	2
7	Fasten plate screw	2
8	Cylinder	2
9	Cylinder sealing ring	2
10	Outlet valve	4
11	Fasten part	2
12	Fasten part screw	1
13	Cylinder head sealing ring	2
14	Cylinder head	2
15	Head cover screw	8
16	Air filter	1
17	Valve plate	2
18	Intake valve	2
19	Metal gasket	2
20	Right fan	1
21	Crank	2
22	Crank screw	2
23	Crank bearing	2
24	Connecting rod screw	2
25	Right crankcase	1
26	Screw	4
27	Light spring washer	4
28	Stator	1
29	Nut	4
30	Rotor	1
31	Motor bearing	2
32	Anti-vibration feet	4
33	Spring washer	4
34	Nut	4
35	Elbow bend	2
36	Metal hose	2
37	Check valve	1
38	Solenoid valve	1
39	External protector	1
40	Screw	2
41	Capacitor box	1
42	Capacitor	1
43	Pressure switch	1
44	Connector	1
45	6 way connector	1
46	Safety valve	1
47	Quick coupling	1
48	Pressure gauge	1
49	Power cable	1
50	Nut	1
51	Rubber feet	1
52	Spring washer	1
53	Screw	1
54	Drain valve	1
55	Air tank	1
56	Screw	2
57	Caster wheels	2
59	Nut	2