



No.	ΠΕΡΙΓΡΑΦΗ
1	Adjustment cover
2	Screw ST4×16
3	Adjusting knob
4	Dial
9	Capacitor
10	Switch
11	Soft handle cover
12	Inductor
13	Carbon brush cover
14	Screw ST4×16
15	Screw ST4×16
16	Line pressing board
17	Sheath
18	Cord
19	Handle
20	Screw ST4×16
21	After floor
22	Stator
23	Screw ST4×55
24	Wind figure
25	Bearing 626zz
26	Brush holder
27	Copper set of
28	Brush
29	Rotor

No.	ΠΕΡΙΓΡΑΦΗ
30	Bearing 608zz
31	Bearing plate
32	Screw ST4×8
33	Bearing 608zz
34	Blade assembly
34A	Blade base
34B	Blade
35	Bearing 6000zz
36	Bearing plate
37	Screw ST4×8
38	Housing A
39	Housing B
40	Screw ST4×20
41	Black wheel A
42	Black wheel B
43	M8 nut
44	Belt
45	Belt cover
46	Screw ST4×16
47	Lock kond
48	Supporting
49	Parallel guide
50	Open end wrench
51	Dust bag
52	Board set